- Inspect the bolts, nuts and screw.
- Inspect the thrust bearing shim and housing for any damage.
- Inspect the roller for any damage.
- Replace all the damaged parts by new one.

Assembling

Assembling is the reverse process of the dismantling.

Result

Thus the given steering gear box was dismantled, inspected and reassembled.

BAE_Practical.indd 238 12/20/2019 2:35:28 PM