3.9.3 Lay shaft

It is mounted at the bottom of the gear box casing. Different gears are mounted on the lay shaft depending on the speed of the gear box. The picture of lay shaft can be seen in Figure 3.9.3.



Figure 3.9.3 The picture of a lay shaft of an automobile gear box

3.9.4 Gear box output shaft or main shaft

It is located at the top of the gear box casing at straight line with the input shaft. Slots are present in this shaft. Through this shaft the power is transmitted to the propeller shaft.

3.9.5 Reverse gear shaft

The smallest shaft in the gear box is the reverse gear shaft which has only one gear called as the idler gear. It is fitted on the gear box casing. This shaft is used for transmitting the power from the lay shaft to the main shaft.

3.9.6 Speedometer drive

Skew gear is connected with the main shaft. With the skew gear a cable with a small gear is connected at one end and the other end of the cable is fitted at the dashboard of the driver. This drive is used for knowing the speed of the vehicle. The picture of a speedometer drive can be seen in Figure 3.9.6.



Figure 3.9.6 A picture of a speedometer drive

3.9.7 Gear selector mechanism

On the top of the gear box, an arrangement with a lever with a gear knob, selector rod and shifting fork are connected. This arrangement is called as the gear (shifting) selecting mechanism. Gear selector mechanism is used for selecting the required gear for the required speed of the vehicle. The picture of a gear selector mechanism can be seen in Figure 3.9.7.



Figure 3.9.7 Gear selector mechanism

BAE_ENG_Chapter_03.indd 49 12/10/2019 11:28:17 AM