4.0 Introduction

Propeller shaft is the most important part of transmission system of a vehicle. It is located in between the gear box and the differential unit. One end of the propeller shaft is connected to the gear box and the other end is connected with the differential unit, and transmits the engine power to the rear wheels. The two ends of propeller shaft are connected by the universal joints and hence the engine's power is transmitted to the rear wheels without any losses even with the difference in distances. For operating the propeller shaft based on various load conditions of vehicle, sliding joint is fitted in between the universal joint and propeller shaft. The propeller shaft withstands the full accelerating power comes from the gear box.

4.0.1 Propeller shaft

It is made of hardened steel and in tubular form. Two propeller shafts are used if the vehicle length is more. Bearing is fitted between the centre of two propeller shafts.

4.1 Material for the propeller shaft

Propeller shaft is generally made up of alloy steel. Moreover it is made up of spring steel material.




Figure 4.0.1 Propeller shaft

BAE_ENG_Chapter_04.indd 56 12/10/2019 11:29:22 AM