Comparisons between Hotchkiss drive and Torque tube drive

S.No	Hotchkiss	Torque tube drive
1	Two universal joints are used.	Only one universal joint is used.
2	Slip joint is required.	No slip joint is present.
3	Propeller shaft is mounted in open space.	Propeller shaft is closed and placed in the torque tube.
4	Propeller shaft will bend and change its length.	No such changes occur.
5	The power and brake force are on both sides.	The force will be acting on only one side.

4.15 Maintenance of the Propeller shaft

- Lubrication must be provided periodically at the slip joints in the propeller shaft by using the grease
- Lubrication must be provided for the universal joins by using grease
- After cleaning the bearings they must be lubricated with grease.
- Bearing cup, spider, circlip and seal must be tested and lubricated

Student Activity

1. Visit any automobile depot nearby you and study the repair work of the heavy vehicles, working of propeller shaft and its types and submit a detailed report of your visit.
2. Visit nearby depot and study the construction of the heavy vehicle differential unit and its working and submit the report
3. Study the faults occurring in the differential unit by visiting a nearby depot and submit your inspection report.

BAE_ENG_Chapter_04.indd 69 12/10/2019 11:29:25 AM