```
servo.write(90);
```

Because the servo only moves at one speed, when we need to slow things down we need to break large jumps in position down into smaller movements with delays between each movement. This might look something like the following:

```
for (int i=45; i<136; i++) {
  servo.write(i);
  delay(10);
}
```

This is a fairly standard sweep using a `for` loop that starts the servo at 45º and increments by 1º every 10 milliseconds until it has reached 135º. In order to return to the starting position at the same speed, we would need to reverse the loop. Take the code in Listing 9-5 for example.

Listing 9-5. *Double Servo Sweep Source Code*

```
#include <Servo.h>

Servo leftServo;
Servo rightServo;

void setup() {
  leftServo.attach(10);
  rightServo.attach(9);
}

void loop() {
  for (int angle=0; angle<180; angle+=2) {
    leftServo.write(angle);
    rightServo.write(180-angle);
    delay(20);
  }
  for (int angle=180; angle>0; angle-=2) {
    leftServo.write(angle);
    rightServo.write(180-angle);
    delay(20);
  }
}
```

In this sketch, two servos are used to sweep in opposite directions, maybe for a pan and tilt mechanism for a camera or sensor, or a pair of wheels for a robot. To do this, two instances of the Servo library are created named `leftServo` and `rightServo` attached to pins 9 and 10. Beginning at 0º and continuing through to 180º at 2º increments, the first loop writes this angle to the first servo while the opposite angle, by subtracting the current angle from 180, is written to the second servo. The second `for` loop reverses the direction at the same speed. A delay of 20 milliseconds is added in each loop to slow the servos down. To slow them down even more, we could reduce the increment or decrement to 1 and increase the delay time. Alternatively, we could speed things up by increasing the increment and decrement counter and decrease the delay.

While there are additional functions that can be used to read the location of the servo, write a position with microseconds instead of angles, and even detach the servo, but these are all somewhat situational. Let's move on to another kind of motor that is also known for its positional accuracy, but can spin 360 degrees.