Code	Character	Code	Character	Code	Character	Code	Character	Code	Character
43	+	62	>	81	Q	100	d	119	w
44	,	63	?	82	R	101	e	120	x
45	-	64	@	83	S	102	f	121	y
46	.	65	A	84	T	103	g	122	z
47	/	66	B	85	U	104	h	123	{
48	0	67	C	86	V	105	i	124	|
49	1	68	D	87	W	106	j	125	}
50	2	69	E	88	X	107	k	126	~

The ASCII codes also contain something called escape codes. These characters have been around for a while and control things like character returns, tabs, and line feeds or newlines. Later in our example code, we use the sequence `'/n'`, which is one of the control characters, a non-printable character that controls the behavior of a device, to signal when a line has been entered. Table 10-2 provides some of the common escape codes.

Table 10-2. *Escape Codes*

ASCII	Sequence	Description
8	\b	Backspace
9	\t	Tab
10	\n	Newline or line feed
13	\r	Carriage return

Finally, how fast we send our packets of information is called the data rate or sometimes the baud rate. This is a measure of how many pulses are being sent or received in one second, also known as bits per second (bps). A sort of de facto standard baud rate for the Arduino is 9600 bps although the microcontroller is capable of communications at a range of speeds up to 115,200 bps, as needed by whatever specific devices that the Arduino is connected to. Both the sending and receiving device need to be set to the same data rate to ensure that both devices are speaking at the same speed.

With the boring basics for using serial communications out of the way, let's turn our attention to the next project and some of the Serial functions available to us.