```
for (int i=0; i<14; i++) digitalWrite(i, HIGH);
delay(1000);
for (int i=0; i<14; i++) digitalWrite(i, LOW);
delay(1000);
```

By substituting `i` in `digitalWrite(i, HIGH)` with the current iteration of the loop, this source code will turn on all 14 pins in order so quickly that it will appear that they all come on simultaneously. The rest of the code pauses for 1 second, turns each of the pins off, then pauses for another second. If you connected a series resistor and LED to each pin, then this code would blink all 14 LEDs on and off every second. To create a more interesting pattern, we could rewrite the sample like the following:

```
for (int i=0; i<14; i++) {
  digitalWrite(i, HIGH);
  delay(1000);
}
for (int i=13; i>=0; i--) {
  digitalWrite(i, LOW);
  delay(1000);
}
```

The first `for` loop will turn on each of the 14 pins individually, pausing for 1 second between each one, starting with pin 0 and ending with pin 13, until all of the pins are on. The next loop begins with pin 13 and ends with pin 0, turning off each pin individually with a 1 second pause in between each one until none of the pins are on.

digitalRead()

With a digital pin configured as an `INPUT`, we can read the state of that pin using the `digitalRead()` function. Its syntax is fairly basic, as follows:

```
digitalRead(pin)
```

Here, we specify the pin number of the `INPUT` pin using either a variable or a numerical constant. What we do with this reading depends on maybe two different ways to use this function. The first is to assign the state of the pin to a variable. The second is to use the function in the place of a variable. For example, if we take the following statement:

```
sensorState = digitalRead(sensorPin);
if (sensorState == HIGH) digitalWrite(ledPin, HIGH);
```

In these two lines of code, `digitalRead()` is used to read the input pin and this reading is assigned to a variable. The next line performs a conditional test on the variable and if this variable is equal to `HIGH`, then it will make an output pin `HIGH`. We could rewrite these lines of code in one functionally identical line instead, as follows:

```
if (digitalRead(sensorPin) == HIGH) digitalWrite(ledPin, HIGH);
```

This somewhat compact line of code uses the `digitalRead()` function in the place often occupied by a variable, so that if the reading of the sensor pin is equal to `HIGH`, then the rest of the line is executed.