

A Uninstall Office XP, delete the folder it creates in the Program files and also delete the registry entries (type **regedit** from **Start > Run** and navigate to **HKEY_LOCAL_MACHINE/Software/Microsoft/Office** and delete the folder). Make sure you take a backup of the registry before making any changes to it. Now reinstall Office XP and your problem should be solved.

Using AVG in Windows NT

Q I have a Pentium III 500 MHz system with 128 MB RAM and a 10 GB hard drive with two partitions. One is of 2 GB (C) with FAT Windows NT 4.0 and service pack 6 installed and the other is 8 GB (D) with NTFS Windows 2000 professional installed. Of late I am facing a problem: when I run the anti-virus package AVG 6.0 from the C drive and try to scan drive D, it shows a line at the top: 'page_fault_in_nonpaged_area' and restarts. After restarting I went

through event viewer of NT and found an entry named 'Save Dump'. When I opened this event it showed me the following lines: 'the computer has rebooted from a bug check. The bug check was: 0x00000050 (0xc2080000, 0x00000000, 0x00000000, 0x00000000). Microsoft Windows NT [v15.1381]. A dump was saved in: C:\NTSERV-ER\MEMORY.DMP.' What's the problem?

Pravesh Taparia

Via e-mail

A The problem seems to be related to AVG 6.0 and NT. Uninstall AVG, delete the folder it creates in the program file, and also go to the registry and delete the entries created by this program. Make sure you take a backup of the registry before deleting any entries. Then try reinstalling it.

Partition Problems

Q I have a P-III 450 MHz based system with an Intel 440BX motherboard and

Award BIOS V4.51PG.

I recently bought a 20 GB hard drive to add to the existing 6.4 GB hard drive. The 6.4 GB hard drive is the Primary Master with Windows 98 SE and Red Hat Linux 7.0, CD-ROM-primary slave. The 20 GB hard drive is set as a secondary slave with the entire space being extended into DOS partition without any primary DOS partition. I have the following problems: In the standard CMOS settings in the BIOS, I have disabled the 20 GB hard disk by selecting None in the corresponding column. In spite of this, both Windows and Linux recognise all the partitions and I am able to read/write data from/into the 20 GB hard disk. The second problem is that the moment I enter User in the standard CMOS settings in the BIOS and go to Windows, there appears an additional partition along with the existing partitions on the 20 GB hard disk, displacing the existing partitions' drive letters. In addition, this partition is inaccessible and Windows issues a 'Cannot read from drive E' error message when I shut down Windows.

Lastly, the hard disk activity indicator LED does not turn off when I try to shut down either Windows or Linux.

Dileep S.

Via e-mail

A To solve the first problem, go to the BIOS and disable the IDE controller or disconnect it. Now you won't be able to read or write data from that hard drive.

Regarding the second problem, it seems that that particular partition has not been formatted and is thus inaccessible. So if you are sure that there is no data on this partition, format it and you will be able to access the partition.

Lastly, it is absolutely normal to see your hard disk LED indicator till you shut down

your PC completely. It will turn off only when your computer is switched off completely. So, there is nothing to worry about.

Hardware

Of DVDs and soundcards

Q I have recently bought a Pentium 4, 1.5 MHz system with 256 MB RDRAM and an Intel motherboard. I also have an SBLive! Platinum soundcard and an ASUS GeForce 2 32 MB graphics card. The speaker system is a DTT2500. My problem is that although I can play DVDs, the Dolby Digital indicator in the amplifier of my system has not yet detected the Dolby Digital signal as mentioned in the user's manual of the DTT2500.

I am told that while using SBLive! Platinum and DTT 2500, only the amplifier (DTT2500) needs to be connected using a S/PDIF cable and no line out and rear out is required. But when I remove the rear out and line out connection, I don't get any sound while playing MP3s or other music files, but there is no problem while playing a DVD. Can you verify this and tell me how I can test that these connections are made right?

The third problem I face is that when I changed over from Windows 98 to XP, I was unable to install the driver CDs and software of either the Creative soundcard or the ASUS graphics card. How can I use the demos and the remote centre, etc of the SBLive! Platinum?

C. J. Mathew

Via e-mail

A In order to playback Dolby Digital signals using your DTT 2500s, you will need to drive these speakers digitally. These speakers have a digital input that can be supplied by your soundcard. The SBLive! should have a Digital Out connector—you

Cannot detect Web cam

Q I have the USB Card and the Intel Create and Share software for my Web cam. I have installed the card and the software in my PC. Everything works fine until the PC attempts to detect the camera, at which point the PC hangs and then restarts. After restarting, the following error shows up: 'inst30.hlp files is missing in the CD. Try to reinstall the software'. What should I do now?

Shishir

Via e-mail

A Download the latest drivers from the manufacturer's Web site and the error should be fixed. Also, you are having problems with fully installing the software as you probably have no space on your hard disk. Free some space on your hard disk by running the Disk Cleanup utility or delete some data.

