

To completely remove this worm from your machine, follow these steps:

Shut down your computer and then restart after a minute or so. Boot in safe mode and then go to MS-DOS prompt. Type **copy regedit.exe regedit.com** and press [Enter]. (**C:\windows > copy regedit.exe regedit.com**)

Start regedit. Go to HKEY_CLASSES_ROOT\.exe (.exe and not exefile further down in the list). In the right side of the window double-click on 'Default' or 'Standard'. Next, in the 'Edit' dialog box, delete the value corresponding to exefile and click 'OK'. Navigate to HKEY_CLASSES_ROOT\rnjfile and delete rnjfile.

Select the Edit menu, click 'Find' and in the dialog box enter **rnjfile**. Now all the infected keys will be shown one by one. Change the key and press [F3] to go to the next key till no trace of this file remains. Now restart your computer.

You should also look for files such as xromeo.exe, xromeo.*, xjuliet.chm, xjuliet.*, Sysrnj.exe and sys-rnj.*, and delete them from

Fuzzy monitor

Q I have a 15-inch monitor with a Pentium III based machine. I recently got a cable Internet connection and also purchased a four-point Jetway Artis speaker set. I usually keep my computer on the whole night, as I download something or the other. In the morning when I try to use the computer I have to degauss my monitor as the screen looks hazy view and blurred. Why does this happen? Is my



monitor about to conk off?

Rahul Lobo

Via e-mail

A There is nothing wrong with your monitor. The problem you are facing is because of the placement of your speakers. You have probably placed the speakers or the sub-woofers extremely close to your monitor. The high magnetic field emanating from the speakers causes your monitor to get a blurry look. Place your speakers further away from your monitor and your problem will be solved.

your system. Now your machine will be completely rid of this virus.

Hardware Bringing the scanner and printer together

Q I have a Pentium III 500 MHz machine with 128 MB RAM and an inkjet printer. Recently I purchased a scanner with a parallel port interface. My machine has only one parallel port. How do I access both devices at the same time?

Pooja

Via e-mail

A All scanners that use the parallel port have two parallel ports at the back panel. One is marked 'To computer' and the other, 'To Printer'. All you need to do is first detach the printer cable from the computer and reattach it to the scanner. Then take the scanner cable and attach it to the computer. This way the scanner mediates between the printer and your computer, and both devices can be used simultaneously.

Unwanted lines

Q I have a UMAX 2000P

scanner, which has been used only occasionally and hence, is as good as new. But of late it has been showing regularly spaced, light, horizontal, straight lines on the scan. The machine is otherwise working perfectly. What could be the cause for these lines and how do I remedy this? The scanner has been installed using its original CD. Does it need a downloadable driver(s), which could improve its performance?

R.M. Pradhan

Via e-mail

A The problem is not driver related. Dust has probably settled on your fluorescent lamp or there might be a problem with the CCD, which is unable to process the full data. As a result you get those lines across your scans. You should get the fluorescent lamp cleaned, but since this is a sensitive component and involves opening up the scanner, consult an authorised technician to solve your problem.

Serial port disabled

Q I have recently purchased a new machine. I connected my mouse to one of the serial ports and my modem to another. My problem is that my modem does not get detected at all.

DVD won't play

Q I recently bought a DVD and played it on my DVD drive for the first time. I have a licensed Cyberlink ASUS DVD 2000 DVD player. With the help of DVD Genie I found that the DVD was not region specific. But whenever I played the DVD, it would play for around 10 to 15 minutes, or sometimes longer, and then the computer would hang. I have tried to play it repeatedly, but to no avail. I downloaded a program called DVD Info from www.visualdomain.net, which described my DVD drive as RPC2 locked and the default supported region is 5. I tried



changing the region settings through DVD Genie, but there's no difference. The DVD I purchased works perfectly on my friend's PC. Please suggest a solution.

Salroy

Via e-mail

A There is nothing wrong with your DVD player or the DVD you purchased, as it plays fine on your friend's system. The problem lies with your system. Playing a DVD involves high CPU utilisation and if your

machine hangs after 15 minutes of play it clearly indicates that your CPU or your system is not being cooled sufficiently. As a result your machine hangs. Check to ensure that there are no gaps between the heat sink and the CPU.