

same settings that you added in the browser, as provided by your system administrator. Now FlashGet will be able to download files for you as usual.

Can't play Medal of Honor

Q. I have a P-III 500 MHz machine with an ASUS TNT M64 32 MB graphics card and a 20 GB hard disk. I recently purchased the game Medal of Honour. I installed it successfully, but when I tried to play the game it gave me an OpenGL error. I went back to the dealer and he said there was no problem with the CD he gave me. Please help.

Anurag

Via e-mail

A There is no defect in the CD and there's nothing wrong with your system either. Apparently, you are using an outdated set of drivers. As a result, when the game requires to use the OpenGL functionality of your graphics card, the drivers can't initialise that functionality and you get this error. Download the latest set of drivers (called the Detonator 4 v28.32) for your operating system from www.nvidia.com and you will be able to play the game.

Monitor refuses to display

I tried to change the resolution of my 17-inch monitor from 1024x768 to 1152x864 and the refresh rate to 85 Hz. It was working fine, but when I restarted my machine the next day, after the Windows 98 boot up screen it showed 'Out of Sync Range'. I tried to restart the machine and boot in safe mode. However, I am using a USB keyboard and it does not get initialised unless the machine starts loading Windows. I tried to use another monitor to rectify the problem but the situation remains the same. Please help me.

Vivek

Via e-mail

A There's nothing wrong with your monitor or graphics card. The monitor displays the 'Out of Sync' message because you have set a refresh rate that the monitor does not support at that particular resolution. To solve your problem, you will have to boot in safe mode and reset your display to a lower resolution and refresh rate settings.

However, apparently, you haven't enabled the USB keyboard support from your BIOS and as a result you are unable to boot into safe

mode. You should go to the BIOS (press [Del] when the Power-on Self Test screen comes on during boot up) and enable USB keyboard support in your BIOS menu. This will solve your problem.

Once in safe mode, you'll be able to uninstall the display card drivers, restart your machine and reinstall them. Your problem should now be solved.

CD-ROM problem

Q. I have a 48x CD-ROM. I've had it for the past two years and it's been working fine so far. But recently when I inserted a Video CD in it, it scanned the CD for some time but refused to play. I tried to eject the VCD from the CD drive but nothing happened. I shut down my machine and switched it on after some time and again tried to eject the VCD and still nothing happened. How can I eject the CD?

Nimish Patel

Via e-mail

A Apparently the CD is jammed in your CD drive. In order to remove it you will need an extremely thin and sharp object that can be inserted in the front panel of the CD drive (usually just below the CD



Open your jammed CD-ROM tray by inserting a pin in the front panel

tray). On inserting this, the CD tray will eject the CD-ROM.

Clearing CMOS

Q. I had specified a password to access my CMOS and have now forgotten it. I can no longer access my BIOS. Is there any way I can get the CMOS cleared?

Natrajan

Via e-mail

A Yes, you can reset the password by clearing the CMOS. Unscrew your cabinet. Locate the CMOS clear jumper on the motherboard; it's usually located near the battery. Keep the motherboard manual handy for reference. Most CMOS clear jumpers have three pins or two pins that you will need to short. If it has two pins, short the CMOS by touching a metal object to both the pins or by putting a jumper on both the pins.

If the CMOS has three pins, move the jumper from one set of pins to the other to discharge the battery. Make sure that the computer is switched off and the power cord is unplugged when you do this. If you can't identify the jumper, remove the battery and let the CMOS discharge for 10 or more minutes. Reinsert the battery. On going to the CMOS now, you will no longer be prompted for a password.

E-mail error

Q. When I try to retrieve my mail I get the following message: "A time-out occurred while communicating with the server. Account: pop.vsnl.com (1)', Server: 'pop.vsnl.com', Protocol: POP3, Port: 110, Secure (SSL): No, Error Number: 0x800CCC19." What can I do to fix it?

John

Via e-mail

A You can try increasing the server timeout to 1 to 2 minutes. You

can do so by going to **Tools > Accounts > Mail > Properties > Advanced**. If the message continues to appear, there might be a problem with your account settings.

Make sure that you've

entered the correct

username

and password.

Or you may

have a very large

message to down-

load as a result of

which you are get-

ting this error. In this

case, use VSNL's Web mail

interface and delete the file manually.

