



Enabling Java with IE6, fixing Windows startup errors, discoloured monitors, installing modems—find all your answers here

Quick View

Q. I use Windows 98 SE and have Quick View installed on my PC, but when I right-click any file, the Quick View option doesn't appear. Please tell me how to enable this for all files.

Varun Kumar Arya
Via e-mail

A Quick View is by default associated with the file types that the program can view. If it does not appear on common file formats such as DOC, RTF, EXE, etc, you can uninstall and reinstall Quick View. You can do this from **Control Panel > Add/Remove Programs > Windows Setup**.



Installing Quick View

Select Accessories and click Details. If this does not help, open the Registry Editor by typing **regedit** in the Run dialog box (**Start > Run**) and expand HKEY_CLASSES_ROOT*. Under this, create a key named 'shell', create another key named 'QuickView' under shell and finally create a key called 'command' under this. Double-click the Default value and enter

C:\Windows\System\Viewers\quickview.exe as the new value. You will now get the Quick View option with all file types, but two such options with the file types that were originally associated with Quick View.

Downloading with Opera

Q. I have just begun to use Opera 6.03 as my default browser. Whenever I download a file, it opens a window called Transfers. If I disconnect and want to finish downloading later, there is no way to get back to the Transfers window after restarting Opera. Thus, I start downloading some other file to get this window and then resume downloading the previous file. Please tell me if there is any other way by which I can open the Transfers window without such a hassle.

Rohan Naravane
Via e-mail

A To open the transfers window in Opera, click **Window > Special > Transfers**, or use the shortcut key combination [Ctrl] + [Alt] + [T].

Discoloured monitor

Q. My monitor shows a yellowish shade around the corners of the screen. It disappears after 10 to 15 minutes, but reappears randomly. Can you tell me what is the reason for it and suggest a solution?

Rohit
Via e-mail

A This usually happens due to the magnetic field of the speakers mounted

on the monitor and can happen with any monitor if the speakers are placed too close to it. Though the speakers on the monitor may be shielded, this effect does tend to develop over time. You will have to degauss the monitor to get rid of the discolouration—your monitor may not have a built-in option for degaussing, but a service person will be able to do it for you.

Installing modem on Windows 2000

Q. I have a problem installing a modem in Windows 2000. When the modem is detected, it is automatically installed as a PCI communication device. Even if I uninstall it, it is again detected and installed. Please help me.

Roshan Patel
Via e-mail

A Instead of uninstalling the modem, update the driver with the actual driver of the modem. Open **Control Panel > System > Device Manager** and double-click the device to open its Properties. Under the Driver tab, click Update Driver and instead of letting Windows 'Search for a suitable driver', select 'Display a list of known drivers'. Click Have Disk to select the correct driver for the modem and install it.

Sloppy floppy drives

Q. I have an assembled Pentium III 600 MHz PC on an Intel 440 ZX board running Windows 98 SE. I have two floppy drives—1.44 MB and 1.2 MB. Though