



Installation problems, games going haywire, CD-ROM problems, missing drivers, etc. You name it, we solve it

Game for an error

Q. I have a 633 MHz CPU, on an Intel 82810e motherboard with in-built VGA and sound, running Windows Me. I get the following error message when trying to install *Delta Force*: "Intel® 82810 E graphics controller. This video card does not support HWT &L (Hardware accelerated transform & lighting). Delta Force has been optimized for cards supporting HWT &L and therefore will run slower on your hardware. The resolution has failed, please make sure that you have the latest drivers for your video card and run the video test again."

Please help me solve this problem, and if possible include the latest drivers in the forthcoming CDs.

Praveen S Bohra

A Whoops! Sorry Praveen, the problem is not with the graphics drivers; the bitter truth is that your hardware is just not good enough. What you need is a better graphics card, at least a GeForce2. Unfortunately, since you have an i810-based motherboard, you probably don't have an AGP slot. Though it hurts, both your pocket and your heart, you're going to have to do a massive system overhaul if you want to play any of today's games.

Height of AI

Q. I have a Pentium III 1.13 GHz, 256 MB RAM, 80 GB hard disk and an


ASUS V8170 64 MB graphics card, running Windows XP. I have installed games such as *The Hulk*, *GTA: Vice City*, *Enter the Matrix*, etc. The problem is, I can't seem to control the characters, they just move left or right on their own. I don't have this problem with *The Age of Mythology*. What do I do? Also, your Mindware and Playware CDs do not autorun on my computer.

Somesh

A The most basic problem could be a malfunctioning keyboard. Check to see that the arrow keys, or whichever keys you have configured to move left and right, are not stuck—a few sharp taps on these keys will unstick them.

What's more probable is that you have installed, but not configured, some other input device such as a joystick or gamepad. This may cause a conflict and can cause your game to go haywire. Go to your game's control options and disable the use of joysticks.

If the CDs do not autorun, but you can still browse through them, it means that the autorun function has been disabled on your PC. Double-click on My Computer, right-click on your CD-ROM drive and select Properties. Now, click on the AutoPlay tab and then click on 'Restore Defaults'. This will turn the auto play function back on, and you can enjoy our CDs.



Check 'Auto Insert Notification' to enable autorun on your system.

Too many restarts

Q. I have an 8 GB hard disk with two partitions, a 2 GB one and a 6 GB one. My problem is that whenever I run either ScanDisk or Disk Defragmenter on my C drive, it runs properly for a couple of minutes and