

## Caring for Your Printer



- Align the ink cartridge after you've installed it. Use the software bundled with the printer for doing this.

- Always store cartridges in their factory-supplied containers or in a small, zip-lock bag in a cool and dry place.

- To avoid paper jams, clean the inside rollers with alcohol. Set your paper guides carefully when placing paper in the in-tray. Never mix paper types in the same tray. Fan through the sheets to separate them before loading the paper tray.

- Use the paper recommended by your printer manufacturer. Use good quality paper even for printing drafts as it prevents paper dust from clogging the printer.

- Always use your printer's power switch rather than the switch on a surge protector to switch off your printer.

- Over a period of time, the prints you get will become faint and there will be lines running across the page. To restore the original print quality, many inkjets come with a nozzle clearing function



that blows ink through the nozzles to unclog them. Use this feature regularly, especially if the printer has been unused for weeks.

- If you find a leak, don't try to fix it yourself. Call the authorised service centre.

- Air bubbles in the cartridge can cause your printer to shut down. Never shake your ink cartridge as that creates bubbles.

- If you remove a part of your ink system such as the print head or ink reservoir, remember to replace it. Opening the system for even a few hours allows the ink to dry out and clog the print head.

### Selecting the Right Paper

The paper you use greatly determines the print quality. Standard quality paper doesn't provide as crisp and bright an image as paper made specially for a particular inkjet printer. The main factors that affect paper quality are:

- **Brightness of paper:** This is normally determined by the smoothness of the paper. A coarse sheet of paper will scatter light in different directions, whereas smooth paper will reflect more of the light back in the same direction. This makes the paper appear brighter, which in turn makes images on the paper appear brighter. The finish may be described as high gloss, gloss,

soft gloss, or semi-gloss, each reflecting the amount of shine.

- **Absorption:** When the printer sprays ink onto the paper, it should stay in a tight, symmetrical dot. If the ink is absorbed too much into the paper, the dot will spread out in an irregular fashion and the result is fuzzy images and text. The coating on photo papers gives the printed photos the look and feel of photographic prints. Because the coating keeps the paper from readily absorbing the ink, some glossy papers dry slowly. However, quick-dry gloss finishes are common today.

# Kasbekar



The xnu i255 appreciates great photography. It uses vivid photo technology printing and 4800dpi resolution with high density inks, to print the best photos images.

TRUE 4800 DPI RESOLUTION • 5 PI INK DROPLETS • MICROFINE DROPLET TECHNOLOGY • VIVID PHOTO TECHNOLOGY • 17 PPM MONO/9 PPM COLOR • 10W ON RUNNING COST • 3 YEARS WARRANTY  
Call Canon at 1600 33 33 66 or visit [www.canon.co.in](http://www.canon.co.in)

Rediffusion DTP&C/CANON/197