

previous version lets you view PDF files, but you will not be able to use advanced features, such as the search capability.

from your hard drive even if you format it accidentally.

To view the date in DOS, just type 'date' and press [Enter].

Undelete My Data

Q How can I retrieve files that have been deleted from the Recycle Bin, and how can I find the current date using DOS commands?

Kripal Singh

A Irrespective of the Windows flavour you use, files deleted from the Recycle Bin are irrecoverable. This is because Windows does not bundle a utility to do so. MS-DOS had an 'undelete' command up to version 6.22, and the command line tools in Windows 98SE, but this was discontinued in Windows XP. You will need to use a third-party tool, such as R-Studio, Ontrack EasyRecovery or Get Data Back, which will let you recover data

Need For Speed!

I have a Pentium III 600 MHz, 128 MB RAM and an Intel 82815 graphics controller, running Windows 98SE. I wanted to play *Halo*, but the game gave me an error that says, "Hardware acceleration may be disabled, run dxdiag." Also, when I try to run *Need for Speed: Underground*, I get an error that says, "This program has caused an illegal operation and will be shut down." What do I do?

Arshad



A You will face such problems when you try to run newer games. This is because your onboard graphics controller cannot support the game that you intend playing. The minimum system requirements for *Halo* are at least a Pentium III 733 MHz processor, 128 MB RAM and a 32 MB video card that supports Hardware Transformation and Lighting. So you need at least an nVidia GeForce2 or an ATi Radeon 9200SE. You will need to upgrade to be able to play most new generation games.

Mole In Internet Explorer

Q I run Windows XP Home Edition, and my e-mail client and Internet Explorer display an unknown Web page as default. Though I set IE's start page as 'blank', the unknown page still shows up. I even reinstalled IE, but to no avail. It is annoying me no end.

Swarup Mondal

A Looks like you have spyware on your computer. The best solution is to install anti-spyware tools such as SpyBot or Ad-Aware, and scan your entire system with them. These software check and prompt you to remove all spyware applications present on your hard drive. This should solve your problem, and also prevent future applications from installing.

QUESTION
OF THE
MONTH

20 Questions?

Q I have an Intel Celeron 1.7 GHz CPU, 128 MB RAM and an Intel 845G motherboard, running Windows XP Home.

I have a few questions:

Are refilled cartridges hazardous for printers? What do I use to clean the rollers? What paper should I use to avoid paper jams? Can you give me some buying tips on how to choose the right CD-R? I have a GTA 4 anti-CD check crack, how do I use it? How can I run PlayStation CDs on my computer? What software do I use to get DVDs to run on my machine?

Ishan Raut Desai

A Now that's a lot of questions! Let's take them one at a time: Yes, refilled cartridges sometimes leak, which may damage your printer, and also give poorer quality printouts.

You can use alcohol to clean the rollers of the printer. This is a generic solution. You may want to consult your printer's user manual to check the exact type of liquid that you can use to clean the rollers.

Regarding the type of paper, choose any good quality printing paper as long as it is not translucent or too thick. Bond paper is the best type of printing paper but may be expensive in the long run. The paper thickness is not an issue as bond paper is the normal recommended paper type for all printers.

Original game CDs are copy-protected, and thus cannot be replicated using software such as Nero Burning ROM. Copying game CDs is illegal! If this problems occurs even when burning a new compilation, or copying CDs that aren't copy-protected, your CD-Writer might be faulty. Send it to the manufacturer's service centre for repairs.

Using no-CD check cracks is illegal. We suggest you buy your own CD.

You can run PS1 and PS2 game CDs on your computer using emulators such as Bleem!. Make sure you own the original PlayStation CDs, or you will be heading into illegal territory here again.

DVDs only play on a DVD ROM drive. Since, you have not mentioned what drive you have, we will suppose it's a DVD ROM drive, and that you are asking about DVD movies. Install software such as Power DVD or Win DVD to watch DVD movies on your computer. Data DVDs can be accessed using Windows Explorer.