


Shoot-Store-Edit-Share-Enjoy



Store

Memory Stick- Store your precious images and movies in the convenient and highly durable Memory Stick Storage media. With Memory Stick, you can transfer files to a host of compatible digital devices.

PC without Memory Stick Slot- Your Cyber-shot can double as an external drive for you to download or upload files from your Memory Stick to your PC, by using a standard USB interface.

Edit with Picture Package™

Experience the fun of creating slideshows using your images. With Picture Packages™, you can use your PC to combine your photos with pre-installed sounds or even MP3/WAV music files. Picture Package software is bundled with year 2004 Cyber-shot new models. Add in special effects and words, then burn your slideshow into a convenient VCD format.

Share

With a Cyber-shot Digital still Camera, there are so many ways to share the fun and enjoyment.

Connect Direct and View on TV/PC - Use Picture Package editing software (supplied) to create slideshows, then burn onto a VCD and share interesting clips with your

friends on TV. You can even enjoy large-screen viewing of your images by connecting your Cyber-shot to a TV using an AV cable.

Mobile Devices - More ways you can enjoy your photos! Download your images onto your Sony CliE PDA or Sony Ericsson phone to use as personalized wallpaper or send it to your loved ones via Memory Stick or MMS.

Do-it-yourself Home Printing - All new Cyber-shot digital still cameras support the industry standard PictBridge™ technology, which makes it possible to connect directly with a PictBridge printer via the USB cable, and print images without using the PC. Or use Sony's own Digital Photo Printer (DPP-EX50), with PictBridge™ to print superb digital photographs directly from your Cyber-shot. With its high quality dye-sublimation print method and high speed processing, the DPP-EX50 lets you enjoy, brilliant and professional quality photo prints.

Now when you go on a vacation, be sure you have your Sony Cyber-shot to capture your precious moments for life. Use the above-mentioned software and techniques and share the moments with your loved ones who couldn't be with you on your vacation.

Accessories you need to carry

Batteries

The action never ends. Ensure that you are always prepared with additional batteries with Sony's rechargeable batteries and quick chargers.



Carrying Cases

Taking your Cyber-shot outdoors has never been easier or safer. The two-way style you can select from is shoulder carry or waist pouch along with Mini pouch and shoulder strap.



Lens Adaptor

Enhance your vision. Get closer to the action with a tele-conversion lens or capture more with a wide-conversion lens.



Memory Stick™

Memory Stick™ enhances your Cyber-shot and enables easy editing, viewing and sharing of photos. Simply insert your Memory Stick™ in any device with a Memory Stick™ slot and record your still images, high quality videos or high volume data.



Cyber-shot

SONY

WIDEST RANGE AVAILABLE



DSC-P150
MRP Rs. 29,990/-



DSC-F88
MRP Rs. 22,990/-



DSC-P100
MRP Rs. 20,990/-



DSC-P73
MRP Rs. 18,990/-



DSC-W1
MRP Rs. 20,990/-



DSC-P43
MRP Rs. 15,990/-



DSC-P41
MRP Rs. 13,990/-



DSC-P32
MRP Rs. 12,490/-