

INTEL® PERCEPTUAL COMPUTING SDK

GETTING STARTED

HARDWARE AND SOFTWARE REQUIREMENTS

The SDK requires the following hardware and software requirements:

- Hardware requirements:
 - o IA-32 or 2nd Gen Intel® Core™ processor with Intel® 64 architecture
 - o 500 MB free hard disk space
 - o Creative® Interactive Gesture camera
- Software requirements:
 - o Microsoft® Windows® 7 or Windows® 8 operating system with SP1 or later
 - o Microsoft® Visual Studio® C++ 2008 with service pack 1 or newer

CAMERA SETUP

It is recommended to install the camera on top of the computer or laptop lid, and plug the USB connection into one of the USB ports, as illustrated in Figure 1.

When performing gestures, it is expected that the user leans back on the chair in a relaxed position. The user's hands move around a virtual plane roughly 12 inches away from the camera. This virtual plane serves multiple purposes: (a) it activates hand tracking when the user's hand is within 12 inches from the camera; (b) the swipe gestures use the plane to distinguish between a left swipe and a right swipe.

It is also recommended that the user's head is always 8 inches away from the user's hands. The hand tracking software cannot reliably distinguish a hand from a head if they are too close to each other.

To avoid fatigue, it is critical that the user finds a relaxed position to satisfy the above two requirements.

SOFTWARE INSTALLATION

Run the SDK installer `intel_pc_sdk_ia32_5057.msi` (32-bit), or `intel_pc_sdk_intel64_5057.msi` (64-bit). The last build number may vary depending on the releases.

You will see a welcome screen as illustrated in Figure 2. Follow the instructions to complete the installation process. By default, the SDK installs to the `C:/Program Files/Intel/PCSDK` directory. Note that if the SDK installer detects any existing SDK versions, the SDK installer will prompt you for an upgrade. It is however recommended




Figure 1: Camera Setup Position



Figure 2: Installer Welcome Screen

to always do a clean uninstall and then install any new SDK versions.

After installation, the SDK installer will prompt you for a system reboot. This step is critical to propagate all environmental variables.