



Coursea goes mobile

The online learning environment has been brought to the mobile platform in both iOS and Android
<http://dgit.in/CourseraFreeApp>



3D weaved shoe soles

A patent pending 3D weaving device can create complex patterns that can be used as shoe soles and stab-proof vests
<http://dgit.in/3DWeavingDevice>

Q&A

external hard disk, the problem is that I'm only able read/write into the hard disk only via Windows and not via Mac.

I know the problem is with the file system, Mac is FAT and Windows is NTFS. But can you recommend me a software or a driver that would enable me to write into the hard drive with Mac?

—Brijrajsinh Gohil

A Hey Brijrajsinh Gohil, You can format the hard drive as HFS and then use a software called HFS Explorer to access the files in Windows. This way you'll have to carry a separate pen drive with HFS Explorer which you'll have to install if you wish to access the said hard drive on any other computer.

Q I have an internal hard drive of 320GB. I want to extend the C: Drive which is mere 20GB (to atleast 100GB). Let me know how can I do the same.


—Bijaya Giri

A Resizing your hard drive is pretty easy in all operating systems. Start off by right-clicking on 'My Computer' and select 'Manage'. In the computer management console on the left-hand section you'll find a header that says

'Storage', click on it. On your right you'll see all hard drive partitions listed. You'll first need to shrink the other drive by whatever size you need to increase the first partition with. If you can't gather enough space you'll need to clear your USN journal and then de-fragment your drive just to get all the data together. Then proceed with shrinking the other partition by 80 GB (in your case). Once the shrinking process is done with, right click on the first partition which you wish to increase and select 'Extend'. This should eat up whatever space was generated from the previous process and resize your partitions. This method doesn't affect your program installation but it takes a lot more time.

A simpler approach would be to backup everything from the second partition before deleting it and extending the first partition, then you recreate the second partition again and restore the backup. This will unfortunately mess up your program installations (not all of them).

Q Hey everybody! I had a system with Windows 7 installed. I had to change the motherboard and the process as the old ones were fried but when I started up my PC after installing



NCQ increases overall performance

the hardware I was not able to boot into Windows (It crashes on the "starting windows" screen and it restarts) but when I change the SATA controller mode to RAID it works fine. Which SATA mode do I need to choose? I have two HDDs installed [320GB(OS) + 1TB].

I have a pre assembled PC from HP with the following specs:


- MSI 7613 motherboard
- Intel Core i3 540

—Karan Verma

A You need to choose AHCI mode for SATA to primarily make use of two features; hot-swapping and NCQ. Hot swapping allows you to pull out your hard drives when the computer is running (Use the Safe to Remove option while doing so). Makes it work like a really bulky and large high-capacity thumb drive.

NCQ allows the hard drive to optimise the path that the head has to follow to access multiple portions of the hard drive. This reduces the time taken to transfer data. RAID is for when you put the two hard drives in combination to increase performance or generate redundancy or both.

You should always take a backup before swapping out the motherboard, however, in your case we assume your motherboard must have given away before you could have taken the backup. Now that you have everything working fine and dandy you might want to take a backup. Set the hard drive controller to AHCI and then proceed to restore the image, if it doesn't work you can still set it back to RAID and restore the images onto the individual drives. Or you can let it be and continue with your work. **1**



Resize your partitions easily using the management console