



No more reading glasses

Researchers are developing a new display technology that would correct vision problems on a TV or laptop screen <http://dgit.in/NoReadGlass>



Sling launches Slingbox

Sling Media recently published an upgrade to its Slingbox line of gadgets and applications, including another entry-level Slingbox M1. <http://dgit.in/SlingboxM1>

Q&A

A Hey Vipul,

1. Did the USB ports stop functioning when you installed Windows 7? If so then those are probably running off a different chipset for which you'll have to install the appropriate drivers. Those ports which are running off the chipset will function without installing any extra drivers. If you still have Linux installed then do boot Ubuntu and then check if those affected ports are working or not. If not then you will have to open the chassis to locate the data cable for these USB ports. They're often part of the motherboard or they're situated on a small daughter board. If in your case, it is the latter then pluck the connector out and clean the contact points before putting it back in. If that doesn't work you'll have to take your laptop to a service centre.
2. When you boot your computer for the first time you are given the option to create recovery disks for your computer. If you'd created those then you can simply put the disk in and bring your computer back to its default configuration. Any extra applications that came with the laptop might not be there but you will get the OS and the recovery partition back. If you didn't make the recovery disc then you need to take it to a service centre to get the OEM OS installation. You can always download the HP drivers online and use open source software to create backups if that is all you need to achieve.

Windows on MacBook?

I have a MacBook Pro OS X Lion and I want to put Windows 7 in it through Boot Camp. I have Windows 7 in a folder downloaded but when I burn it to a disk and then insert it in the Mac and start Boot Camp it says, "Please insert the Windows 7 disk." But in Finder it shows the CD and the files. I tried to make it ISO file and also .dmg then burn it onto a CD but both of them didn't work out. Please let me know how to install it.

—Debasmit Mandol

A Hey Debasmit,

It seems that your disc is not bootable. You'll need to re-download the operating

system installation image and try again. Often, if there is any glitch during the download process then the integrity of the image is affected. Also, pirated operating systems won't work since most of them have some sort of modification which affects the integrity hash. If the hash verification fails then the disc is considered as non-usable.

Drive unreachable

Dear Sir,


My PC configuration is given below:

- OS - Win XP Service Pack 2
- CPU - G2010 @ 2.80GHz
- RAM - 2 GB
- HDD - 500 GB

Please find the attached screen shot.

Why this problem is showing every time I try to access the said drive.

—Premananda Moirangthem



Often caused due to virus infections

A Hey Premananda,

It seems that your file associations have been corrupted. This can be due to OS crashes or due to malicious software that weren't properly removed or was too entrenched in the system to be removed properly by any means. There are easy fixes for all your file extensions. Simply head over to this website (<http://dgit.in/XPassoFix>), download the individual registry fixes and execute them with an administrator account. This should fix all your problems.

Erratic monitor behaviour

Hello guys,

I have been a long time reader of Digit and it has always helped me in many tech problems I have had. Here's a problem that has been bugging me for a few weeks. I had done a clean install of my system after 3 years to dual boot Windows 7 Ultimate and Linux Mint 16 (Earlier I used Windows 7 Home Premium). After that I installed all the drivers provided in my motherboard CD. All of them got installed fine except the NVIDIA display driver which gave

errors during installation. So I downloaded it from the motherboard's website and installed it again after uninstalling the previous one. The downloaded drivers got installed perfectly but still my monitor is not detected in display properties and I can't set the highest resolution. It says 'Default Monitor'. And everything appears a bit blurry and ugly on it. Videos appear weird and games are not running (except really old ones). Also a thin black band resides on the right side of the screen. However, in Linux Mint, my monitor is perfectly detected and everything runs fine. I tried to look in my monitor's website too but I got no help. Could you please help me out of this headache? Here are the required details of my config:

- Motherboard - ASUS M4N68T-M-LE-V2 (AM3)
- Monitor - Dell IN2020M
- CPU - AMD Athlon II X3 445
- OS - Microsoft Windows 7 Ultimate 32-bit

Your help will be greatly appreciated.

Thank You and Keep Up The Great Work!

—Bishal Dey



Yes, monitors have drivers too!

A Try installing the driver for the monitor. Yes, monitors have drivers too! You can either let Windows download on its own through the Windows Update feature or get it from Dell's website which we've hyperlinked here. <http://dgit.in/IN2020MDriver> Let us know how it works out. 