



## Mac mini M2

Easy-err to open

**Satvik Pandey** | [satvik@digit.in](mailto:satvik@digit.in)



### Getting the lid off

The first thing you need to do when tearing down the Mac mini M2 is to take off the base plate. It is your gateway into the internals of this device. You will need to use the spudger tool to take the cover off the shiny metal plate that is held down by screws. The six screws holding down the metal plate can be removed using the TR6 Torx Security Screwdriver. Just leave enough space after removing the plate to expose the coaxial antennal cable, which is held down using another T6 screw. Next, use the spudger to take off the protective plate.



### Fan the flames

No, we don't mean setting the Mac on fire. Not yet at least. The next step into the guts of the Mac mini M2 is the removal of the cooling fan and heatsink. Once you have completed the base plate removal, loosen the T5 Torx Screws. Then use the spudger to help you disconnect the fan header from the main board.



### Power out

The power supply is held in place by three T6 screws, and once they have been removed, all you need to do is use a set of tweezers and remove the retention clip, which is located under the AC inlet. Rotate the now-free inlet by 90 degrees, and you will be able to pull out the power supply from the housing.