

<code>Serial.print ("\tSignal: ");</code>	
<code>Serial.print (WiFi.RSSI (thisNet));</code>	Print signal strength of the Wi-Fi network.
<code>Serial.print (" dBm");</code>	
<code>Serial.print ("\tEncryption: ");</code>	
<code>Serial.println (WiFi.encryp- tionType (thisNet));</code> <code>}</code> <code>}</code>	Print encryption type of the Wi-Fi network.
FUNCTION TO READ WORDS (MULTIPLE ALPHABETS)	
<code>int readSerial (char result[])</code> <code>{</code>	Function to read sentences or words as they contain multiple alphabets and 'Serial.read ()'. Reads only one alphabet and stores the word or sentence in the variable passed to it.
<code>int i = 0;</code>	
<code>while (!)</code> <code>{</code>	
<code>while (Serial.available () > 0)</code> <code>{</code>	When data is available at serial port
<code>char inChar = Serial.read ();</code>	Read the data (single alphabet) and store in variable 'inChar'
<code>if (inChar == '\n')</code> <code>{</code>	If user enters Line Feed (next line) character (commonly known as using [Enter] key)
<code>result[i] = '\0';</code>	Set the character to escape sequence, called NULL TERMINATOR. Used to end sentences.
<code>Serial.flush ();</code>	Delete all serial data
<code>return 0;</code> <code>}</code>	
<code>if (inChar != '\r')</code> <code>{</code>	If the entered alphabet is not CARRIAGE RETURN
<code>result[i] = inChar;</code>	Store the alphabet in the variable passed
<code>i++;</code>	
<code>}</code> <code>}</code> <code>}</code> <code>}</code>	Count variable to avoid overlapping of characters in final variable which has data stored, in this case 'result'.

Since we're only connecting to the Wi-Fi network and not doing any further processing, we'll leave the loop() function empty and stop the program after trying to connect to the Wi-Fi network.

Using the Motor Shield

The Motor Shield used on the Arduino™ board is based on the L298 motor driver IC. It can drive inductive loads such as relays, solenoids, DC and