


Code for driving a Stepper Motor

A Stepper Motor is slightly different than a DC motor. The stepper motor uses pulses of current to drive the motor.

You can find a copy of the code at <http://dgit.in/ardsteppercode> and related explanation at <http://dgit.in/ardstepperexp>.



Connecting a Stepper Motor to the motor shield

Using the GSM Shield

We'll divide the GSM Shield code to send and receive SMS into two separate sections just to make it easy to understand.

The Arduino™ GSM Shield connects the Arduino™ board to the internet using the GPRS wireless network. All you need to do is plug the shield on top of the Arduino™ board and plug in your SIM. It also allows to make and receive voice calls (with an external speaker and microphone attached) as well as send and receive SMS messages.

The mobile network is also a reliable option in many cases over the internet in case of emergencies.

To use the GSM shield, you'll need to download Arduino™ IDE version 1.0.5 as there are bugs in Arduino™ IDE version 1.0.6 for the GSM shield.

Receive SMS

The following code snippet allow you to send SMS using the Arduino™ GSM shield. It can be very useful in developing applications that allow you to control hardware through SMS. Further, the data in the message can be tested using conditions to perform specific actions such as switching ON and OFF the AC at home.

You can find a copy of the code <http://dgit.in/ardrecsmscode> at and related explanation at <http://dgit.in/ardrecsmsexp>.

Send an SMS

Though we can receive SMS using the Arduino™ shield and control many