

Code	Explanation
from twisted.web.server import Site from twisted.web.resource import Resource from twisted.internet import reactor	Imports the Twisted Python server libraries.
import RPi.GPIO as GPIO GPIO.setmode(GPIO.BCM) GPIO.setmode(18, GPIO.OUT)	Imports the GPIO libraries which contain code similar to the code for LED blinking
class lampAPI(Resource):	
def render_GET(self, request):	Define render_GET function
if 'motor_status' in request.args:	Checks if the variable 'motor_status' exists in the received URL.
if request.args['motor_status'][0] == "off":	Checks if the parameter for the 'motor_status' variable has been set to 'off'.
GPIO.output(18, False)	If the user sends the 'off' parameter, this command switches OFF the motor / solenoid.
return "Motor / Solenoid has been turned OFF"	Informs the user that the Motor / Solenoid has been switched OFF.
if request.args['motor_status'][0] == "on":	Checks if the parameter for the 'motor_status' variable has been set to 'on'.
GPIO.output(18, True)	If the user sends the 'on' parameter, this command switches ON the motor / solenoid.
return "Motor / Solenoid has been turned ON"	Informs the user that the Motor / Solenoid has been switched ON.
root = File("myserver")	Specifies the server files storage folder as 'myserver'.
root.putChild("pi_auto", lampAPI())	Creates a child to handle requests.
serve = Site(root)	Initialises the 'twisted' object.
reactor.listenTCP(80, serve)	Sets the server to handle request on port 80.
reactor.run()	Keeps listening on port 80 forever until turned OFF manually.