

loop. You could use as an alternative – a small silver piece called kill coil. This is because silver could act as a natural biocide. It's a pretty good idea since you won't have to add extra liquid to the coolant.

An anti-corrosive

This is necessary only if there are multiple metals in the loop. For instance, if the loop has copper waterblock and copper radiator, you don't have to use this. But on the other hand, say, you used a copper block with an aluminium radiator, an anti-corrosive would be needed in the coolant.

Dish soap(just a drop or two)

This would act as a surfactant. It can also help rid of the bubbles that may generate in the loop. Behold the immense potential of the humble dish soap!

Colouring

Colouring is another additive that you may use but one which is not actually recommended. This is because color additives tend to gum up the works. So, if you do want color, it's best to opt for colored tubing instead.

If you're buying the different parts separately, ensure that all the parts are compatible.

How to put together the components

Once all the parts are procured, you can then proceed to put everything together. The process is a bit complex but if you take it slow and follow the instructions, the water loop should be up and running without incident. So, take a deep breath and follow these steps:

1. Planning out the loop

First of all, look within the case and plan how the loop would work. Find out where the reservoir and the pump could be mounted with the included hardware. Also, figure out where the radiator would fit and the order in which you're gonna connect the parts.

The reservoir should come right before the pump inside the loop, so that the pump never actually runs dry. If the reservoir isn't built for a drive bay, you'll need to either mount it on



The perfect loop starts at the drawing board!