

If the case is big enough, the radiator could be mounted on the vent the fans go to. Then, you could screw the fan to the radiator. If the case is larger, you'd probably mount it in the bottom. If such options are unavailable, you would have to mount it externally. Use the brackets that come with it for this.

The pump and reservoir could be mounted with Velcro or the mounting hardware which come along with them. If you've a bay reservoir, you could simply slide it into place and screw it into the side, just as with a DVD drive.



Get the connections right!

4. Connecting the tubing

Start with screwing the fittings into all the components. After that, start connecting the tubing. One end of the tubing could be slid over a fitting. After that, you should measure how much of tubing you'd need to connect the thing to the next component in the loop. After marking it using

your finger, the tube should be cut with a pair of scissors, as straight as you possibly can.

Then, the tubing's end should be connected to the next component. This process should be repeated with every piece of hardware.

If you find that the tube makes too sharp a turn and kinks, it's bad for the water flow. If this is the case, go back to the planning stage and figure out how you could make the bend without the kink.

Also, if barb fittings are used, to secure them use zip ties or hose clamps, even if the tubing looks like it's well-fit.

5. Filling up the loop

Before you do this, have some paper down within the computer. In case a leak springs, plug it up and empty the loop. Give the system some 24 hours to dry.

Before filling up, you should jump the power supply. This would help you test the pump and also the fans without turning the computer on. The 24-pin cable has to be disconnected from the motherboard. The green wire should be connected to the black wire with a paper clip.



Fill it up the right way!