

After this, add the liquid additive if needed. For this, put a funnel on the reservoir's fill port. Pour the water in. The reservoir should be filled nearly to the top. If some empties into the tubing, it's fine. After the reservoir gets filled up, the power switch in the computer's back should be flipped on. Allow it to run for a second.

Once the reservoir is halfway down, turn the computer off before the pump is dry. It's crucial that the pump never runs dry since this could damage the pump for good in mere seconds. After letting some water out of the reservoir, fill it to the top yet again. The process should be repeated until the water level in the reservoir stays constant. Check the loop for leaks.

6. Testing for leaks and bleeding the air bubbles out

The final step involves letting the whole loop leak-test for 24 hours. Allow it to run but check frequently to ensure there is no leaking. Also, during these hours, a lot of the bubbles in the loop will bleed out. To aid this process, you may have to shake the case or maybe tap the tubing. If a very few small bubbles are left over, it's no reason to worry. They will drain away in time.

Once it's ensured that the system is completely leak-free, turn it off before reconnecting the 24-pin motherboard cable. Closing everything, you can use the computer.

You would find that the computer's temperatures have come down significantly. Also, you'd find that you could run the fans at significantly lower speeds and still keep everything much quieter. About every six months or so, you should empty the loop and rinse out the hardware. **d**