

install a custom ROM and any attempt to do so will void the warranty of your device. It also puts your phone at the risk of ending up in a bricked state.

Why bother unlocking the bootloader?

The answer to this is extremely simple. If you want to root your phone, chances are it is because you want to flash a custom ROM onto the rooted device. Your device cannot support a custom ROM installation unless it comes with an unlocked bootloader.

If you plan on unlocking your bootloader, there are a number of places where you can find help. Make sure you are looking at instructions specific to your model type. Here are a few examples -

- For OnePlus3, visit <https://dgit.in/OPBL>
- For Sony phones, visit <https://dgit.in/SonyBL>
- For Stock Android OS like Google Nexus One, visit <https://dgit.in/StockBL>

Superuser and Modules

Right after you are done rooting your device, one of the first things to do should be installing a superuser app. While rooting your device will give you complete and full control over your device – the superuser app is the button that you need to use that control. In order to install any other apps that need rooting, you will need permission to be granted via the superuser.

While a lot of permission managers are out there, the forerunners among the lot are SuperSU and Magisk. This part of the chapter focuses mainly on Magisk Manager and its modules. And mainly because Magisk comes integrated with the Xposed Framework. Read on to know more.

Magisk Manager

Consider Magisk a systemless interface. It allows you to update your device at your own pace and with peace of mind. It just makes the whole process so much



SuperSU is a popular permission manager for superuser controls



Magisk has a number of useful modules available