

apps in it, you will need to deodex the apps. Select the deodexing option from the kitchen menu and let the process run.

Now before you move to actually modifying the apps you also need to understand about deknocking the ROM. This is needed for some of the high end phones which come with an in-built Knox warranty. This warranty is voided if you root your device or modify the ROM. If you use official firmware on a device with voided Knox warranty, there will be a lot of problems like high battery usage etc. To remove Knox, open up Kitchen and select **deknocking the ROM**. Then open up the app folder inside the system folder, look for any folder containing the word Knox and delete them. Next, open up the **system/lib** folder and search for **libknox** and delete those files too. Now go to the **build.prop** file (open it with Notepad++) and look for the line 'ro.config.knox' and change its value to 0 so that it reads 'ro.config.knox=0'. Similarly, change the value of 'ro.config.tima' also to 0.



Phones with in-built Knox warranty require additional steps to deknock the ROM

In The Beginning...

Once the working folder is ready, open up Cygwin and go to the kitchen menu. Type 0 to go to advanced options and type 23 to convert **update-script** or **updater-script**. Then press 1 since you have the updater-script and want to convert it to the update-script. Once this is done, you will be again taken to the kitchen menu.