

Type 10 to see the working folder information. It will extract the kernel and randisk. You will see the information of the working folder like Android version, ROM name and a list of yes or no values for several data points like is the phone rooted, /data/app enabled etc. If busybox is not installed, you need to install it and the working folder needs to be rooted.

Go back to the kitchen menu and select option 2 to add root permissions. You will see that Superuser.apk is being installed inside the folder. To add busybox type 3. Press Y, hit enter and wait till busybox is installed.

To change the name of the ROM, open the file titled build.prop with Notepad++. Go to line ro.build.display.id and you will find a string of alphanumeric characters after the =. You can change this string to anything of your choice and that will be the name of the ROM you are building.

Now, let's reduce the size of this ROM. Your ROM contains a lot of unwanted apps that take up space and battery. You need to remove these unwanted files to optimise your ROM. All the apps are located in the system/

app folder. You can remove the unwanted files either by using File Explorer or the kitchen. You can simply delete the apps you don't want but be careful. Don't mess around with this if you don't know what you are doing. Some apps are required by Android to run. Check on XDA forums to find the list of apps which are safe to remove and which are not.



Getting rid of unnecessary apps is one of the main reasons to use a custom ROM

The safer way is to do it from the kitchen- it separates the unwanted or

'bloat' files. Open up Assayyed kitchen and select the option 'Debloating the ROM'. Next select CHOOSE_LIST and you will see the available debloat list. Select the appropriate list like 'ASSAYYED KITCHEN LIST' and the kitchen will start the debloating process. After it ends, go to the WORK folder and you will see a bloat folder. Move this folder out of the ROM directory to another location, in case you need it later.