

```
CPUClassic" android:action="android.intent.action.MAIN"
android:targetClass="it.sineo.android.noFrillsCPUClassic.
activity.MainActivity" />
• </PreferenceScreen>
• <PreferenceScreen android:title="@string/cpu_stats"
android:key="cpu_stats" android:summary="@string/cpu_
stats_summary">
• <intent android:targetPackage="com.bvalosek.
cpuspy" android:action="android.intent.action.MAIN"
android:targetClass="com.bvalosek.cpuspy.ui.HomeActivity" />
• </PreferenceScreen>
• </PreferenceCategory>
```

Now Save and close both files. Recompile the files i.e. insert the edited files back into the settings.apk file and make a flashable .zip file using the same. The next step would be to flash the new files and reboot to have the changes take effect. Basically, you now have access to the CPU live stats and can edit the same. Dropping the clock by 50-200 MHz should solve your heating issues. The reduction varies from device to device and you should Google to figure out what works best for your device. Dropping the clock too much will cause your phone to not function at all, so be careful.

If you begin doing your research, you might find a number of other tweaks and mods out there that could go way beyond your imagination (and ours too, perhaps). Keep hunting those developer forums and you might end up finding tweaks for your custom ROM that are like matches made in heaven. Either way, tweaks or no tweaks, flashing a custom ROM is a pretty cool thing to do. And we are hoping we have managed to show you how to get it up and running and how to end up with a device that's really fresh and awesome. 