

removable. Do this once you've emptied out your coolant. Then use some pressurised water with mild acid such as vinegar to clean the microchannel. Keeping the base plate submerged in vinegar for 30-60 minutes is also an easy way to get the gunk to separate on its own.



The microchannels can get stuffed

Once the base plate is cleaned out, see if you can get a new gasket for your pump as replacing the gasket is always advisable each time you open your pump. The gasket is what ensures that your coolant does not come in touch with the electronics within the CPU block or leak outside the cooler.

There are the simple methods for ensuring the smooth functioning of your CPU cooler. If you find any of these complicated, then there's always YouTube to the rescue. **d**