



Matching the ID and OD measurements between the tubing and fittings is all you need to worry about.

looking for fittings, these are the measurements you should be matching. So, if you're buying soft tubing, then you match the ID of the tube with the diameter of the barb fitting. However, if you're going for a compression fitting, then you need to match the ID and OD of the soft tube with the ID and OD of the compression fittings too. In hard tubing, you need to consider only the OD if you're using push-in fittings otherwise you have to consider both the measurements if you're opting for compression fitting.

You might be wondering which diameter should you choose for your system. Although there isn't much of a difference in the flow in different diameter tubes, there will be other things you should consider. For soft tubing, you already know that they are prone to kinking or collapsing when they bend too much. Hence, you are required to install anti-kink coils in the area where the kink happens. It isn't necessary that your tubing will kink all the time and one way to avoid it is to avoid any sharp curves in the loop, especially close to the fittings. Another alternative could be using thicker



Avoid sharp curves to prevent kinking in soft tubing or install anti-kink coils at the required places