

## Prepare the water blocks

The first step in the assembly process should be installing the water blocks on your components. They should be ideally given a wash with distilled water before you install them. Whether you're cooling just your CPU or graphics card, you must disassemble them appropriately. For the CPU, you don't really have to do much, unless you're going to delid it which is for advanced builders only. Take out the block and backplate meant for your CPU socket. Attach the backplate behind the motherboard. Apply some thermal paste and install the water block. If you're cooling the graphics card as well, then you will have to first disassemble it. Remove the chassis and heatsink until you're left with just the PCB. If you're cooling with a full block, then you will need to attach thermal pads to the rest of the components including the chokes, memory modules and VRM. Clean the existing thermal paste on the GPU and apply some fresh paste. Finally, you can attach the water block.



Thermaltake Pacific WI CPU water block



Thermaltake Pacific V-GTX 10 1080/1070 Nickel Full Cover Transparent GPU Water Block

## Setup the radiator

A new radiator usually arrives in a pristine condition. However, it's always a good practice to give it a preliminary flush with some good old distilled water. In order to do so, install the stop plugs to seal all the openings except the two ports for the flush. Flushing the radiator is easy. Remove the lock ring from the compression fittings and install the fittings on these two ports. More on this later. Use PVC tubes or a funnel to add distilled water into the radiator and let the other port drain it out. Repeat it for two or three times and let it dry. We will assume that you've already decided where you're going to install the radiator in your case. You can start with installing the