



Thermaltake Pacific
RL360 Radiator

fans, followed by mounting the radiator into your case. Secure the cables from the fans so that they are tucked away nicely and don't interfere with the radiator or fans. You have to make sure that the two ports of the radiator don't hinder other components since that's where your tubing will go.

Install the pump and reservoir

The next part you need to handle is the pump and reservoir or the combo. We've already mentioned how it's easier to deal with a pump and reservoir combo and this is where it stands out. In your case, you might need to remove your drive cage or PSU shroud to make room for the combo if it's a large one. Otherwise, in some cases, you can make do without changing up much with a smaller sized combo. What you need to keep in mind is that there must be enough room on the top for the tube coming from the radiator. There should also be enough space at the bottom port from where the fluid from the reservoir is being pumped to the loop. The other port on the top of the reservoir should ideally be close to the open side of the chassis so that it's easier to pour the fluid. Also, if your pump and reservoir combo happen to have a drain valve, it should face the open side of the chassis for ease of access. You will need to install the mounts to the combo which will be used to install it inside the chassis. Whether you want to install the combo vertically or horizontally is up to you and the space inside your case. You will generally find mounts to support both the orientations.