

Pouring the coolant

It's finally time to introduce the coolant into the loop. But before doing that, you have to prepare for the worst and that is leaks. Place paper towels at the bottom of the chassis and below the tubes, especially near the fittings. Even though your system won't be turned on, wiping them dry becomes a tedious and long process further delaying the build. In case the loop leaks, it will drop on the paper towels and they will absorb them. Hence, you should avoid thin tissue papers and go for thick paper towels. Open the stop plug on the reservoir and start adding the coolant using a filling bottle. The advantage of using a filling bottle is evident with the extended pipe at the outlet to prevent the liquid from pouring out. Investing in a filling bottle or syringe is a great choice since it also makes maintenance easier when you're trying to drain the loop. If you don't have a filling bottle, you can also use a funnel to pour the fluid.

As you start filling the reservoir, the coolant won't flow to the rest of the loop on its own. You will need to pump them to flow throughout the



Filling bottles can be used for both filling and draining the reservoir