



Overclockers user *marzipanius* showing how his tubes turned yellow

place paper towels over your components below the tubes. After the tubing is out of the system, you can rinse them with normal distilled water. Leave them to dry and avoid using a hair dryer if it's a hard tube. It might bend and not fit in your custom loop. Avoid any type of aggressive chemicals for your tubing and reservoir since it might damage them. Now you can go for the radiators, water blocks, reservoir, pump and fittings. For radiators and fans, you can refer to the next section below.

The dirtiest part in the entire system is usually the water blocks where a lot of gunk accumulates over time. Remove the water block(s) and open up the screws and washers. Holding the blocks under running warm water, you can start brushing off the residue using a soft toothbrush. For a finer clean, you can use toothpaste. Avoid any exotic variants and go for a basic one. When you're done washing, wipe them dry. After giving the water blocks a preliminary wash, you can give them a second round of cleaning up with chemicals, especially copper blocks. Slightly acidic cleaning solutions such as white vinegar and lemon juice are recommended. Another run of washing with distilled water should also be repeated after this. For copper water blocks plated with nickel, avoid any form of chemicals since it can damage the plating. It's best to use warm water, wiped with a soft cloth.