

4. Cutting and sanding the copper board

Sanding the copper board makes it simpler for the board to absorb the pattern that you are ironing on it. However, before you sand the board, you will be required to cut the board properly. Keep margins before you start. These are precautionary measures to ensure your board is of the perfect size even if you go wrong somewhere.

5. Preparing the pattern

This is probably one of the most important steps of your procedure. You will need a laser printer and glossy paper for this. While printing, make sure the glossy side is where the pattern or the circuit is being printed. Orienting the page properly is of utmost importance. This is the page that will determine the final working of your set up.

6. The procedure of transfer

The procedure of transfer involves ironing the pattern onto the copper board. To do this successfully, you might have to sacrifice your iron. Hence, do not use an expensive one or one that you don't want to be ruined.

Cut out a piece of cardboard and some sandpaper. Put the piece of glossy paper on top of the copper sheet. Make sure the print out is facing the sheet. Attach it to the copper sheet with some tape. Now place the sandpaper on top of the glossy page, and the cardboard on top of the sandpaper. Place some paper towels on top of this arrangement. If you are lucky, this will protect your iron from the pieces of gunk.

Once the iron is hot, place it on top of the towel. Press it hard for a minute and then remove it. Make sure heat has been applied to all parts of the board, especially the edges because that is where it lacks. Hold the iron there for another minute or two before finally removing it.

Be careful while removing the extras. The cardboard will be very hot and you do not want to hurt your fingers.

Once you are done with this process, it is time to bathe your little setup. Do not worry if pieces were still sticking to your board after ironing. This is the finishing touch for your board. Keep the board immersed in a container of warm water. The board should be placed face up. Let it stay for some time, ideally about ten to fifteen minutes. After that, take the board out and peel out the paper. Upon peeling out, you will be left with a copper board with your pattern on it.