

But suppose you wanted the system to output a different line on startup, what should you do? Locate the pi directory in the home window. Open a sample notepad file for editing by typing in:-

- `sudo nano sample.py`

And enter the following code and save it:-

- `#!/usr/bin/env python`
- `from subprocess import call`
- `call(['espeak "Text" 2>/dev/null'], shell=True)`

Hardware and Software

One way to run a program on Raspberry Pi at startup is to execute the local rc.local file. Commands can be added to the program while Pi boots making it quite useful if the program is executed without a connected monitor. Open the file in the system and edit it from the /etc/rc.local directory using the editor of your choice. Configure the root permissions to save any changes:-

- `sudo nano /etc/rc.local`

Add commands to execute the python program by referencing the file location. Be sure to leave the line exit as O at the end, then save the file and then exit. In nano, to exit, type Ctrl-x, and then Y. If the program runs on an iterative loop, the best option is to add an ampersand at the end of the

