

printed on the keys, and then in a light circular manner, swab each of the keys.

- IV. Now, dry up the keyboard/keys with a clean microfiber cloth. Do not insert batteries, or plug in the keyboard until it has completely dried.

Cellphones and Tablets

These two gadgets are by far the most widely used electronic items by us and are exposed to the maximum amount of risk compared to other gadgets. Before initiating your clean mission, do not forget to switch off your smartphone and tablet.

- I. Keep in mind that to clean your smartphone and tablet, all you need is a microfiber cloth and a touchscreen-safe antimicrobial spray. Experts are also of the opinion that alcohol-based sprays are effective too. But, we advise you to read your brand's manual instructions before using anything with a chemical base. The use of disinfecting wipes is also recommended to clean your smartphone and tablet's screen and chassis.
- II. Wet your fresh microfiber cloth with the spray or an alcohol-based solution, but remember not to oversaturate the cloth.
- III. Now, slowly wipe the whole screen, except all openings, sensors, and camera space.
- IV. Let the spray or the chemical sit on the gadget's screen for the amount of time as prescribed on the product label.
- V. Dry your smartphone and tablet screens by wiping it with a fresh piece of cotton.

Back covers are easy to wash using microfiber cloth and dish soap.

- I. To wash your back cover thoroughly, first remove it from your tablet and smartphone.
- II. Prepare a solution by mixing some amount of dish soap with lukewarm water.
- III. In the solution, wet the microfiber cloth, but do not saturate it.
- IV. Now, smoothly run the cloth all over the cover to wipe inside out.
- V. Nicely rinse the cloth to squeeze out the dirt and wring it again to make it slightly wet.



Source: images.macrumors.com