

gadget sticky, you can fix this with the help of straw and some rubbing alcohol, without opening the controller's shell.

- IV. All you have to do is saturate the buttons with the rubbing alcohol and agitate the same with the straw.

Televisions and Monitors

Monitors and TV screens are mostly made of plastic, which makes them less resilient than a tablet or a smartphone.

- I. Cleaning your monitor/TV only with a damp soft or a microfiber cloth is the only fruitful option if you do not wish to permanently damage your monitor.
- II. Using harsh cleaning sprays, like Windex and other similar sprays with properties of detergents is strongly barred as the chemicals in these sprays can ruin the surface screen of your TV and monitor, make the display foggy, and leave streaks on the screen. And, if the screen is damaged for once, it is damaged forever.
- III. Few televisions and monitors even have cooling fans placed in their inner body. Keeping in mind, the technology of your television and monitor, removing the accumulated dust from their back, sides, and the top portion is highly recommended because dusting helps dissipate the heat.

PC Cases

PC cases attract a lot dust, and this dust acts as a barrier in the free flow of heat from the PC. To stop the heat from killing your computer's internal parts, it is advisable to clean your PCs on a regular basis. Since the cleaning of this electronic gadget is quite dangerous, it is recommended that you take immense care while reaching the parts to avoid any damage and ensure that you stay on the ground to prevent static discharge.

- I. To successfully clean this gadget, you have to clean each and every component separately by bringing it out of the case. When you dismantle your PC, you can also perform some other relevant maintenance tasks, such as installing additional fans, RAM, GPU, etc.

Smartwatches and Fitness Trackers

Generally, your smartwatch and fitness tracker gets dirty and filthy because of sweat and dust particles that sit on the body when you are out in the open. But, owing to their water resistance capacity, its body and dial can be cleaned easily.