


the current specifications of their device. System clean up tools can also be used in order to optimise software performance to an extent.

7. Boot errors:

Boot errors can occur due to a wide variety of reasons. A number of them are only occasional and do not lead to a permanent shutdown of the machine. On the other hand, other boot errors are caused by problems such as your operating system having been corrupted, rendering the machine unusable. Boot errors can be caused due to malware, overuse of the machine, or even a long period of redundancy. Even if boot errors do not occur all that frequently, the probability that your computer will crash increases significantly, since they point to a problem with your machine which might require repair or correction. These repairs may include the in-built troubleshooting applications installed in the operating system, or even reinstalling your copy of the OS.



Source: cdn.mos.cms.futurecdn.net

Finding out what caused the crash

Finding out what caused your computer to crash is an essential step in the diagnosis of the problem with your computer and its repair. Windows offers solutions that help you diagnose the cause of the PC crash and also troubleshoot any software issues that might have occurred. The Reliability Monitor in Windows allows for quick detection of the problems by showing a list of recent crashes of the systems as well as various applications within the system. The Reliability Monitor was added to Windows Vista in 2007 and has been present in all the Windows versions since. The following are the steps to access and peruse the Reliability Monitor in Windows.

1. Go to the start menu search bar and type 'reliability.' The results should show an option to 'View reliability history.' Click on this option to open the reliability monitor.