

New Devices” list to find your controller’s name. Once you have located the correct name, tap on the name to select it, and bingo! Your Android phone is successfully connected to your controller, which will be indicated on your controller as explained in the previous step.

Note: The above steps may slightly vary depending upon the features of the Android phone that you are using.

Now that you have learned how to connect your PS4/ Xbox One controller with an iOS and Android phone, we think knowledge on how to disconnect the same should also be imparted to you unless you want to be like the famous Indian Mythological character named “Abhimanyu”, who knew how to enter a “Chakravayuh” or a “Labyrinth” but, did not know how to come out of it. So, without implying your distorted knowledge on how to disconnect your controller from your smartphone, just follow the below steps for a smooth exit.

Steps to disconnect a PS4/ Xbox One controller from your iPhone

Once you are satisfied and content playing with the Xbox/ PS4 wireless controller on your Android or iOS phone, here’s how you can go about disconnecting your controller from your phone. The easiest way to disconnect the controllers is by holding down on the Xbox or the PlayStation button for a few seconds. Through your iPhone’s Control Center, the same can be turned off by following the below-mentioned steps:

- If you use an iPhone that is compatible with a Face-ID, open the Control Center on your phone, for which from the upper right corner of your iPhone’s screen you have to swipe diagonally towards the lower-left corner. In the case of a Touch ID compatible iPhone, you just have to simply swipe up from the bottom of the display.
- Now, you need to press and hold on to the blue Bluetooth icon for a few seconds, after which a menu will pop-up where an icon will be shown that says “Bluetooth: On.” You have to press and hold on to this icon for a few seconds.
- “Xbox Wireless Controller” or “DualShock 4 Wireless Controller” will be visible in the popped-up options. Just, press the desired option, and your controller will immediately get disconnected.

There is also a bit lengthy process of disconnection, which is as follows:

- Go to the “Settings” app of your iPhone and select on the option “Bluetooth.”