

Adjusting the WINDOWS 10 Registry for Mining

- When Windows is fully installed and you have started it for the first time; you need to perform the adjustment of the Windows 10 Registry
- It is on the Mining.bat file.
- This optimisation disables everything that isn't important to mining on Windows and disables everything from this tool. Running in admin mode, the Windows registry tweaks once everything is applied,
- Restart the rig

STOP WINDOWS UPDATE # DOUBLECHECK

- Open Run and type services. MSc. open Search for "Windows Update".
- Click Stop if the status is Live or Checked / Being checked.
- Select "Disabled" for "Start-up type".
- Apply and Reboot Repeat Service Tweaks
- 4.4 Increase Virtual Storage
- Open Search, type "This PC", right-click and select "Properties"
- Then, "Click Advanced System Settings "Performance is displayed on the Advanced tab.
- Click Settings "Click the Advanced tab.
- Many GPUs need to add virtual memory.
- Generally, each GPU requires 3GB of virtual memory.
- So, if you have 6 GPUs, you need $6 \times 3 \text{ GB}$ of virtual memory = 18 GB.
- Initial Size (MB) Type: 2000 MB x Number of GPUs (12000 MB for 6 GPU mining rigs, 24000 MB GPUs for 12)
- "Maximum Size" (MB) "Type: 3000 MB x GPU Count (6 GPUs)" 18000MB for mining rigs, 36000MB for 12GPUs)
- Click Settings > OK > Apply.
- Reboot the rig Change the virtual memory

Power Plans and Options

- Open Search and enter: Power Options
- Click Show Additional Plans
- Select a High-Performance Plan, then, for a High-Performance plan, click Change Plan Settings.
- Select "No" for all four options "Turn off display" and "Put the computer to sleep".
- Click No. Change advanced power settings.
- If PCI Express > Link State Power Management, check the following: