


edition test first is a wise step. There is no need to convert GPUs to Compute mode in the Blockchain driver as it's there by default.

If the Adrenaline or Blockchain drivers aren't functioning, try the most recent Crimson ReLive Driver. To do so, go to Radeon Settings and select compute mode for every GPU. Choose CUSTOM rather than Express at the start of the installation process, and only choose "AMD Settings" and "AMD Display Driver." Skip the ReLive installation throughout the setup.



Source: <https://mining.help/>

Device manager showing six detected cards

Optional solution

Restart your computer after installing the driver. It's possible that you won't be able to view your GPUs if you've already updated or modified them. This is most probably an issue with the RX 570 series, while it occasionally happens with RX 580 models. The issue stems from the bios mod, which alters how the GPUs function. You'll need to patch your drivers to get them to work properly, or the driver will just disable or hide the GPUs. This is only required if your bios' changed GPUs are not visible in the Windows Device Manager. 'Pixel Clock Patcher' must be downloaded.

Installation of other GPUs

Power off the PC and plug in all of the other GPUs. When you turn it back