

bigger but it totally skipped the fact that they're phones and the user should be able to use them with one hand. Hence, the one-hand usability went out of the window. So, if a person wants to access some content placed on the top of their screen, they need to use another hand to do that. Well, guess what is placed on the top of your screen? We'll give you a hint, it's in the name of this chapter.

Hence, we bring you the last app for the chapter - "Bottom Quick Settings". This app is a boon for all the people with small hands who just cannot reach their notification shade with one hand. This app does exactly what's advertised. It brings your notification shade to the bottom of your screen. Hence, instead of "swiping down" from the top, you will "swipe up" from the bottom to bring up the notification shade.

To get started with the app, you'll need to do two things. Firstly, download the app from the Google Play Store. Secondly, you will need to turn off navigation gestures for this app to work. You see, even though there is an option to activate the notification shade from the left, right or bottom of the screen, apparently, navigation gestures will definitely get in our way. So, you need to go back to the good old navigation bar for this app. Now that you've done that, open the app and grant the required permission. Then on the 'Handle Position' menu, select the 'Bottom' option. Then keep on swiping till you see the 'Let's get started' screen and tap the 'tick' button. Here, the app will give you a small tutorial regarding which option does what and a brief description of it. Once you're on the home screen, just make sure that you have turned on the 'Service' toggle.

You should now be seeing a small 'white pill' on the bottom of your navigation bar. Without touching anything, go to your home screen

