

- PARAMETERS
- \* /rostdistro: melodic
- \* /rosversion: 1.14.3
- 
- NODES
- auto-starting new master
- process[master]: started with pid [15096]
- ROS\_MASTER\_URI=http://ip-172-31-31-24:11311/
- 
- setting /run\_id to c70b2cce-e773-11e9-9f15-027a087bcd00
- process[rosout-1]: started with pid [15107]
- started core service [/rosout]

At this point, your terminal will get stuck since you have the roscore process running on it. This terminal can be left running in the background and you should fire up a new terminal.

Type in the following:

- `rostopic list`
- `/rosout`

## Step 6 – Conclusion

That should be it. roscore is now ready to accept all your new ROS commands. Your PC is now ready to develop robots. 