



durability. Knowing the best technique is crucial whether you want to simply wipe down the keyboard's surface or pull the keys out and thoroughly clean it. Following are some cleaning suggestions for your keyboard as well as instructions on how to take out the keycaps for cleaning or replacement.

The simplest way to maintain the keyboard

Turn the mechanical keyboard upside-down and shake it to let any loose particles inside fall out in order to maintain it and keep it free of debris. Spray the keyboard gently with canned air to get rid of anything that didn't originally come out. It helps to hold the keyboard in an awkward position so that the crumbs and other debris fall out. Additionally, when spraying the canned air, make quick, brief blasts.

Steps to clean your keyboard

Step 1

1. The little keycaps from the keyboard must first be removed in order to do a more thorough cleaning of the keyboard. If you've never taken a keyboard's keycaps off, watch our instructional video on replacing keys first. It illustrates how to take the keys off of a mechanical keyboard and how to put them back on.
2. Pull off the keycaps with the aid of a key puller. Keep in mind that the form of the keys varies depending on where they are located on the keyboard. With the Das Keyboard Ultimate, it may be particularly challenging to distinguish between the keys. To make it simpler to replace the keycaps after cleaning the keyboard, we advise organising them as you remove them.
3. We highly advise against attempting to take off the return key, space bar or any other large-sized keys. These keys have a support bar underneath them, which can make it challenging to remove and even more challenging to replace the key. The stabiliser bar is connected to the keycap by two little white bits, as seen in the image below.
4. These components can be lost or broken extremely easily if they fly off the keycap when the key is removed. Since there are no replacement parts for these, the keys they

attach to will no longer work properly if they are broken or lost. It is advised to keep these keys in place because they may still receive a very thorough cleaning without being taken out.

Step 2

Shake the keyboard upside-down once the keys have been taken out to allow any loose debris to fall out. Next, use a brush and a can of air to help loosen and remove any last bits inside.

Step 3

1. If anything has poured onto the keyboard, clean the area with a moist cotton towel or microfiber. To assist remove any sticky substances, apply a drop of isopropyl alcohol or diluted liquid soap (1 drop to a gallon of water).
2. Use the cloth instead of the keyboard while applying the liquid. However, if there is any liquid in the switch around the contact, it will keep the connection closed (as it is when a key is depressed) until the water evaporates.
3. Das Keyboard switches have gold contacts because the gold prevents the contacts from rusting. Always consult the keyboard's manufacturer before using it since certain keyboards—aside from the Das Keyboard—do not react well to alcohol and may become harmed by it. The danger of soaking your keyboard in isopropyl alcohol is quite high, but if all else fails, it could be worthwhile to save the keyboard.

Step 4

After replacing the keycaps, clean the tops of the keys and the enclosure with a microfiber or cotton cloth that has been very slightly dampened. If the inscriptions on the keys are so severely unclear that they appear faded, follow the instructions in step 3 and apply a little amount of diluted liquid soap or isopropyl alcohol.

Step 5

1. Invert the keyboard and let it dry overnight. Depending on the environment and the interior temperature, this may take much longer. In any case, ensure sure the keyboard is totally dry before connecting it to a computer and using it.
2. While some articles claim that washing a keyboard in a dishwasher can be successful, putting an electronic device into a dishwasher where it will be saturated with water is extremely risky.
3. The keyboard must be totally disassembled in order to accomplish this, which normally voids the warranty. Because of the salts and minerals in hard water and water from water softeners, corrosion inside the keyboard might occur. It is far better to clean the keyboard with diluted liquid soap or little amounts of alcohol than it is to try to put it in the dishwasher.