





Available wireless networks

Click in the SSID of the network that you wish to connect to and click on Configure button to enter the WEP key.

7. If you do not see any networks listed in Preferred or Available networks, you will have to manually add the SSID. To do this, click Add and enter the SSID and WEP key, if necessary. Click OK, and you should be able to see the network you just added, in



Enter the WEP key for your SSID

the Available Networks box. If you see the correct SSID in the Available Networks box, you're required to click on Configure in order to enter the WEP key, if that is required.

8. In the next window that appears, enter the SSID. If a network key is required, click on 'Data Encryption (WEP enabled)' and then enter the Network Key you've been provided with. If you

enter the key incorrectly, a pop-up message will appear stating 'Incorrect WEP key', and you will have to re-enter the key. While you do this, make sure that the Caps Lock and Num Lock are off all the while. Click OK to close this window. Click OK again to return to the Desktop.

9. Now, click on Start and go to Connect To. You will see some choices pop up. Click on Wireless Network Connection, and your Wi-Fi connection will be ready to work. You can also access this by clicking on Start and opening the



Start working on the wireless network

Control Panel. Open Network Connections and double-click on Wireless Network Connection.

Sometimes, the connection may not work. If this happens, disable your firewall and try to connect. If you can connect with the firewall disabled, you need to change the firewall program settings to allow it to connect to the network. If the firewall is not the problem, you'll need to check the SSID and WEP key you entered. Both these are case-sensitive. These are the problems that you are more likely to encounter. If you're still facing difficulties connecting, contact the Wi-Fi hotspot provider's helpdesk. ■

jayesh_limaye@thinkdigit.com

Prolong The Life Of Lithium-Based Batteries

Li-ion batteries prefer partial discharges rather than full discharges. Frequent full discharges must therefore be avoided. Charge the battery as often as you can.

Typically, a Li-ion battery lasts for around two to three years, or around 300 to 500 charge and discharge cycles, whichever comes first. Over a period of time, the internal resistance of the battery increases due to oxidation. Eventually, the resistance level reaches a point where the battery can no longer deliver the stored energy, although the battery may still have ample charge. Although this cannot be avoided, the rate at which the battery ages can be slowed down.

Avoid exposing the batteries to high temperatures (higher than those prescribed on the battery pack). This is the case when the laptop is always run on the mains with the battery inside. The laptop's temperature rises, and the battery will not last for more than 12 to 18 months. If you use the laptop primarily in your

office, you would use the mains to power the laptop. You can charge the battery and then remove it to store it in a cool place, and continue working. Be sure to periodically charge the batteries, though.

Avoid purchasing spare Lithium-ion batteries for later use, and look at the manufacturing date while purchasing a battery. If you already have a spare battery, charge it to 40 per cent charge and store it in a cool place.

Windows XP also has Power Management features that you can put to good use to lengthen the life of the laptop's battery. Go to the Control Panel and open up Power Options. Under the Power Schemes tab, select the Portable/Laptop scheme. You can tweak this scheme by setting the 'Turn off monitor,' 'Turn off hard disks' and 'System Standby' times to different, lower values. For example, there's no reason to keep hard disks running for longer than five minutes of inactivity.



- Light weight at approximately 1.95kg
- Full featured 12.1" convertible Tablet PC
- Modular bay for 2nd Battery/ HDD/ TV Tuner card
- Superior security feature

LIFEBOOK | STYLISTIC

FUJITSU