



Microsoft's Azure
Microsoft Azure Cloud Computing Services is generally available now.
<http://dgit.in/Microsoftazure>



Pink Macbook

Apple has come up with it new Macbook which has better in performance and available in Rose gold. <http://dgit.in/MacbookPink>

Workshop



STEPS 7:

Remove all screws on board and make sure you remember the specific screws and where the exact one fits as you might end up putting the wrong screws and destroying the threads in the plastic screw slots of your laptop.



STEPS 8:

When all the screws are removed, take out the DVD drive which is attached to your laptop. In this case we have an extra hard disk attached to the laptop in the multibay slot. So just slide it gently and it should pop out.



STEPS 9:

Once you've taken out the hard drives and plastic panels you might come across more screws. Remove these as well. Be careful and don't remove screws that are not required for moving to the next step as you might cause damage.



STEPS 10:

Using any sharp plastic object like a guitar pick or plastic card and slide it in the slit between the keyboard and the chassis. The keyboard should pop out easily. You might have to slide the keyboard upwards or downwards.



STEPS 11:

Unplug your keyboard from the base. Handle the Flat Ribbon Cable (FRC) with caution, just refer to your laptop manual to find out the socket mechanism and then try to remove the FRC. Also, remove the FRC which is connected to your touchpad and power button.



STEPS 12:

Remove all the screws on board and make sure the frame is not held by any of them because if you miss even one screw and try popping the chassis, the cumulative stress on the plastic frame might just rip it straight out. So that's another thing to be careful about.



STEPS 13:

Using the plastic card start removing the plastic casing of the laptop, this will help you unhook the sockets which are holding the frame and then make sure you are not damaging any plastic component of the casing as it will not fit properly if any of it gets broken.



STEPS 14:

Once the casing is removed look for possible wires and FRC attached to the motherboard and remove them, you will possibly find one connecting your screen, connecting your USB 2.0 Hub and the charging point. Additionally, there might be other cables as well.



STEPS 15:

Remove all the screws which is holding your motherboard to the frame and gently unscrew it. After all the screws are removed gently pull the motherboard and carefully slide it to the side which will help you remove the sockets from the plastic casing.



STEPS 16:

Holding the motherboard in your hands gently blow air on the fan and make sure you are holding the fan blades gently with your finger so as to not have it rotate violently. If the accumulated dust is a little thick or tough, switch to a medium brush and dust it off.



STEPS 17:

Now disconnect the cooling fan and proceed to remove the copper heatsink. If you have a discrete GPU then the heatsink might be covering the GPU as well. Don't bend the heatsink while removing it and see if it uses thermal pads of thermal paste.



STEPS 18:

Clean the thermal paste on the heatsink with a tissue and use acetone if necessary. Apply a rice grain's equivalent of thermal paste and then reseat the heatsink. Put the screws back alternately while maintaining equal pressure. Reassemble your laptop.