

Workshop

Take a shot at mastering the browser of the future in this workshop as we show you how to use Opera Neon.

**\$100,000 Headphones**

The Onkyo Diamond Headphones are pair of headphones with 20 karat diamonds and will cost \$100,000 <http://digit.in/OnkyoD>

Notorious multi-function printers, overclocking woes and the iconic Nokia 6600

This month we try to find workarounds for printers that won't scan with empty cartridges, finding a replacement adapter, and how cyber cafe owners can have a hassle free setup to restore their machines.

Q No ink, No scan

Hi Digit,

I have a Canon Pixma MP287 printer. The cartridge inside is empty and whenever I try to scan my paper on it, it displays a warning message saying the cartridge is empty. This doesn't allow me to scan anything. If there are any workarounds to solve this problem, please reply as soon as possible. Thanks in advance and wish you a Happy New Year.

– Rahul

A Hi Rahul,

Looks like you aren't alone as several other owners and users of all-in-one and multi-function printers are facing the same issue. Many manufacturers have locked down their machines to operate the scanning feature only when your cartridge is filled with enough ink to print. We discovered a few workarounds that you can try. Connect your printer with an ethernet cable in the same network of your house and open the web interface for the printer using the IP address assigned to it. You can probably should be able to scan here. If that doesn't work, one popular method used is to hold down the reset button for five seconds that should clear out any "empty cartridge" error from the printer. If both your cartridges are empty, you might have to do this



method twice. Another suggested method is navigating to Control Panel > Devices and printers or Scanners and printers > Select your printer and hit Scan. That should do the trick for your scanning needs.

Q Internal to external

Hi, I'm trying to convert my internal hard disk to an external drive. When I'm trying to format it, my PC slows down and hangs. Please tell me how should I go forward with this. Also, the file type has changed from NTFS to RAW. Please help me out.

– Kanhu

A Hi Kanhu,

Your PC slowing down and hanging could be because of a high number of assorted files already stored in your hard drive. They usually take a lot of time to delete and sometimes due to high load, your PC might start lagging. Try to format your hard drive on another PC by inserting the hard drive in an enclosure and connecting it via USB to the other machine.

Before going forth with the following process, we would suggest you to run a `chkdsk` command from the cmd prompt with administrator privileges. Enter the command "`chkdsk /f X:`" (without quotes) where X is the partition letter. If this doesn't work, try converting the format directly with the command "`convert X: /fs:ntfs`" (without quotes) and hit Enter. Then type M (the name of the partition or disk you want to convert to NTFS) and press Enter. Although this process is

only required if you want to recover the data in the hard drive. Otherwise, with a successful format, you'll be able to change the format right there.

Q A mini problem

Hi Digit Team,

I hope you are doing well. Coming to the point, I have a Connoi mini-PC (Model: NTP2500HN-3311) powered by an Intel Atom processor (2GB RAM & 250GB HDD). Few months back while shifting my house, I lost the adapter to it. Since it was working efficiently and served my day to day activities appropriately, I am not ready to replace it. Can you please suggest suitable adapter to it? Meanwhile, I have sent an email to Connoisseur electronics a month back. But didn't receive any response. Thanks & Regards.

– Chetan



A Hi Chetan, we couldn't find the exact model you've mentioned but the mini-PC listed on their website displays a 90W AC/DC adapter. You'll still need to check your device and find whether they have listed down the ratings. Next, all you need to do is buy an adapter with the same power output and pin.