

WAT on browsers

The WAT add-on enables Thunderbird browsers to open web sites and services directly in the users email software

10 billion Apple downloads!

Apple has announced that its Apps Store now has 10 billion applications, including games and software programs

Blank laptop screen

I have a Compaq V3000 laptop with AMD processor and an NVIDIA graphics card. When i switch on the laptop, the screen remains blank. The service guy I checked it with says that there is no problem with the HDD and RAM is working fine. He saus that the problem is with the graphics card and i need to replace it. It will cost me ₹4,500.

Anuroop Nair

First try connecting your laptop to another monitor, if that monitor turns on, then there is no problem with the graphics card. The backlight of your LCD may have stopped working which needs to be replaced. As you have not mentioned the name of the NVIDIA card that is housed in your laptop, we cannot confirm if the amount you are being charged is appropriate or not. In case the other monitor does not light up, but you notice the system running, then your graphics card is at fault and will need replacement. The reason for non working graphic card can be overheating or physical damage occurring by mishandling of the laptop.

Right power supply

I want to buy a Zotac GeForce GTX 570. But I do not know if my system and power supply support it or not. My system

configuration is : Processor : Intel Core i5-760; Motherboard : P55D Deluxe; RAM : 2 x 2 GB DDR3 1600 MHz; Hard Disk : Western Digital 1 TB. Cooler : Cooler Master V6 GT; Cabinet : Cooler Master Elite 430; Power Supply : Cooler Master Silent Pro Gold 700 W. Please solve my problem.

Pranjit Borkotoky

Your configuration looks good for the card you are planning to buy. As long as you use a single GTX 570 card, the 700 W power supply is more than enough.

Torrents won't download

I am using a LAN 100 Mbps connection. None of the torrent download client is able to download any torrent on my system. The torrents get stuck to 0 percent and don't move forward. I have already used Vuze, BitTorrent, uTorrent, etc. What is the reason? Please tell me the reason. Also tell me how to find this default speed

Ankit Yadav

The most likely reason that the torrent client isn't able to download is because there may not be any seeders sharing the torrent, or there is a firewall which is preventing data from entering your system - in which case you will have to disable your

system's Firewall, Whenever you download a torrent file, you will see something called Seeders / Leechers. There should be more of seeders and less of leechers for faster download of torrent files.

Error Code 43

I have a 250 GB external hard-disk which I use with my Dell Inspiron

15R laptop (Core i5 processor, Windows 7 Home basic, 500GB hard disk drive, 4GB RAM). Everything was working fine till a few days back when I connected my hard disk to my laptop. I got a message, "USB device not recognized." When I clicked on the message, it showed the unknown device properties. It said, "Windows has stopped this device because it has reported problems. (Code 43)". I disconnected the device and connected it but same message appeared again. I tried to update the drive, but it said that the drive is up to date.



On the DVD


Check out recent video reviews of the coolest products

This time we have compared eBook readers

What may be the problem and how can I reuse my hard disk? I have some very important data in it that I don't want to loose it. Please Help.

Paras Basera

You will get a Code 43 error when Windows has stopped the device as it has some problems. It may be due to a faulty driver or faulty hardware ie. USB drive in this case. You should try uninstalling the USB drivers and then restarting the system. Go to Start > Run and type devmgmt.msc. This will open up the Device Manager tab. Double click to expand the Universal Serial Bus controllers. Right click on Host Controller and click Uninstall > OK. Uninstall all the items under Universal Serial Bus controller and then restart the system. Windows 7 automatically reinstalls USB controllers on startup. Try connecting your drive to see if it is working now.



Un-install USB controllers from the device manager and restart PC